

Vorderradkorb

- Ergo-Griff
- abnehmbar
- passend für Quick-Halter „C“

Maße: 34 x 25 x 27 cm

051 021 00 schwarz
 # 051 022 00 silber
 # 051 074 00 weiß
 VE = 10 Stück

Front Basket

- Ergo-Grip
- removable
- suitable for Quick-Bracket „C“

Size: 34 x 25 x 27 cm

051 021 00 black
 # 051 022 00 silver
 # 051 074 00 white
 Unit = 10 pieces

**Vorderradkorb**

- Ergo-Griff
- Lenkermontage, zum Einhängen

Maße: 40 x 31 x 22 cm

051 027 00
 VE = 10 Stück

Front Basket

- Ergo-Grip
- handlebar assembling (to hook in)

Size: 40 x 31 x 22 cm

051 027 00
 Unit = 10 pieces

**Vorderrad-Kinderkorb**

- Ergo-Griff
- Lenkermontage, zum Einhängen

Maße: 23 x 16 x 13 cm

051 030 00
 VE = 10 Stück

Children Front Basket

- Ergo-Grip
- handlebar assembling (to hook in)

Size: 23 x 16 x 13 cm

051 030 00
 Unit = 10 pieces

**Vorderrad-Kinderkorb**

- Lenkermontage, zum Einhängen
- ovale Form

Maße: 25 x 16 x 16 cm

051 076 00 rot
 # 051 077 00 rosa
 # 051 078 00 lila
 # 051 028 00 schwarz
 VE = 10 Stück

Children Front Basket

- handlebar assembling, to hook in
- oval shape

Size: 25 x 16 x 16 cm

051 076 00 red
 # 051 077 00 rosa
 # 051 078 00 purple
 # 051 028 00 black
 Unit = 10 pieces

**Kinder-Fahrradkörbe,
farblich sortiert**

- Lenkermontage, zum Anhängen

Material: Kunststoff

170 070 00 Princess
 # 170 079 00 Winnie the Pooh
 # 170 102 00 Cars
 VE = 4/48 Stück

Children Baskets, sorted by colour

- handlebar assembling

Material: plastic

170 070 00 Princess
 # 170 079 00 Winnie the Pooh
 # 170 102 00 Cars
 Unit = 4/48 pieces

